

---

866.332.2403 (Toll Free); 7am-7pm Pacific Time, Monday-Saturday

## Assembly instructions for: **ADIRONDACK STANDARD OTTOMANS**



# ASSEMBLY INSTRUCTIONS

The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference

**Tools required:** ½-inch ratchet and a mallet or small hammer.



**1** Your ottoman was partially disassembled into 3 parts and hardware (ottoman, two legs, 4 carriage bolts, washers and nuts). Unpack your ottoman and make sure you have all the parts. Turn upside down. You'll notice that each corner has a number that corresponds to each leg. Match the leg number to the corner hole and attach with two carriage bolts. Align the predrilled holes, lightly tap the 2 bolts in. The bolts should tap into their holes. If you have to force a bolt, the leg is probably not oriented properly, is in the wrong hole or it is turned around. Make sure the bolts are tapped all the way into the wood, then add washers and nuts and tighten with a ½-inch ratchet. Do not over tighten or you'll crush the redwood and weaken the ottoman's structure.



Repeat the process in photo 1 for the other leg

Thank you. If you have any questions, please call or email us.