

866.332.2403; Outside the US: 619.600.5630 8am-5pm Pacific Time, Monday-Friday




Assembly Instructions for: **BENCH SWINGS (SEATS ONLY)**



CONTENT OF BOXES

Seat



Quantity	Description	Drawing
1	Seat	
2	Arms	
2	Backrest	

Hardware:

Quantity	Description
2	Chains
2	Springs
12	Quick Links
10	3 1/2" x 5/16" Bolts, washers and nuts
2	Eyebolts 4" x 3/8"


ASSEMBLY INSTRUCTIONS

Thank you for purchasing Forever Redwood patio furniture. Forever Redwood is built by Old-Growth Again Restoration Forestry (OGA). OGA is dedicated to restoration forestry. Sales of patio furniture finance our restoration work in California redwood forestlands.

Tools required: ½-inch ratchet and a mallet or small hammer.

The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference.

Step 1: Attach the armrest to seat and backrest with carriage bolts with washers and nuts. On the edges of the seat you'll find a number written next to a set of predrilled holes. Tap the bolt all the way into the wood to set it, then add a washer and nut and lightly tighten. *Repeat this step to attach the other side and with the other section.*



Step 2: The chain that hangs the swing is one piece for each side. It is adjustable in 2 ways. You can shorten or lengthen the overall height of the swing at the frame or at the eyebolts on the swing seat to get the swing to your preferred height.



Thank you! If you have any questions, please call or email us.