



Assembly Instructions for: **KID'S ROUND OUTDOOR WOOD TABLE**



CONTENT OF BOXES

Quantity	Description	Drawing
1	Tabletop	
4	Legs	
8	3 1/2" x 5/16" Carriage Bolts, Washers and Nuts	
4	8" x 3/8" Carriage Bolts, Washers and Nuts	


ASSEMBLY INSTRUCTIONS

Thank you for purchasing Forever Redwood patio furniture. Forever Redwood is built by Old-Growth Again Restoration Forestry (OGA). OGA is dedicated to restoration forestry. Sales of patio furniture finance our restoration work in California redwood forestlands.

Tools required: ½-inch ratchet and a mallet or small hammer.

The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference.

Step 1: Attach Leg to tabletop with three carriage bolts, washers & nuts (match the numbers written next to the predrilled holes on both pieces). Tap the bolt all the way into the wood to set it. Then add a washer and nut and lightly tighten.



Step 2: Repeat step 1 to attach the other three legs.

Carefully turn the table around. The tips of the legs can be splintered if the table is dragged. It is best to turn the table over with two persons to avoid this.

Thank you. If you have any questions, please call or email us.